



# MANUAL TRANSMISSION ASSEMBLY

## COMPONENTS


MT01A-03



### Separate Seat:



### Bench Seat:




N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

★ Precoated part

D02734



N·m (kgf·cm, ft·lbf) : Specified torque

◆Non-reusable part

★Precoated part