

INSTALLATION

1. INSTALL SPIRAL CABLE ([See page SR-24](#))
2. INSTALL UPPER AND LOWER COLUMN COVERS ([See page SR-24](#))
3. INSTALL STEERING WHEEL ([See page SR-24](#))
4. INSTALL STEERING WHEEL PAD ([See page SR-24](#))