





REPLACEMENT

w/ AHC System:

REPLACE BUSHING

- (a) Using SST and a press, remove the bushing.
SST 09623-36010, 09710-28021 (09710-08031)



- (b) Using SST and a press, install a new bushing.
SST 09623-36010, 09710-28021 (09710-08031)