

REASSEMBLY

Reassembly is in the reverse order of disassembly ([See page TR-13](#)).

HINT:

Coat all of the sliding and rotating surfaces with gear oil before reassembly.