

CRUISE CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

DI26R-04

Troubleshoot in accordance with the procedure on the following page.

