


PARTS LOCATION



- Engine Room Junction Block
- EFI Fuse
 - EFI and ECD Relay

