




CYLINDER HEAD COMPONENTS

EMOKZ-01



B04478



Heated Oxygen Sensor
(Bank 2 Sensor 1)

◆ Gasket

20 (200, 14)

40 (400, 30)

◆ Gasket

RH Front Exhaust Pipe

◆ 63 (640, 46)

Heated Oxygen Sensor
(Bank 1 Sensor 1)

◆ 20 (200, 14)

◆ 40 (400, 30)

◆ Gasket

◆ Gasket


◆ Gasket

◆ 63 (640, 46)


LH Front Exhaust Pipe

N·m (kgf·cm, ft·lbf) : Specified torque


◆ Non-reusable part




A04460




A04327



A04461





N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A05527