



ENGINE UNIT COMPONENTS



EM0LB-01




A05130





A05131





A05114





N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

★ Precoated part

A05120