






















STEERING





SST (Special Service Tools)

PP1B5-01




	09612-22011	Tilt Handle Bearing Replacer	Tilt steering column
	09616-00010	Steering Worm Bearing Adjusting Socket	PS gear
	09630-00014	Power Steering Gear Housing Overhaul Tool Set	
	(09631-00142)	Overhaul Stand	PS gear
	09631-00350	Steering Rack Cover 35	PS gear
	09631-12071	Steering Rack Oil Seal Test Tool	PS gear
	09631-20060	Bearing Guide Nut Wrench	PS gear
	09631-20081	Seal Ring Tool	PS gear
	09631-22020	Power Steering Hose Nut 14 x 17 mm Wrench Set	PS gear
	09633-00020	Power Steering Hose Nut Wrench	PS gear
	09640-10010	Power Steering Pressure Gauge Set	
	(09641-01010)	Gauge Assy	Power steering fluid

PREPARATION - STEERING

	(09641-01030) Attachment B	Power steering fluid
	(09641-01060) Attachment E	Power steering fluid
	09910-00015 Puller Set	
	(09911-00011) Puller Clamp	Power tilt and power telescopic steering column
	(09912-00010) Puller Slide Hammer	Power tilt and power telescopic steering column
	09922-10010 Variable Open Wrench	PS gear
	09950-40011 Puller B Set	
	(09958-04010) Holder	Tilt steering column Power tilt and power telescopic steering column
	09950-50010 Puller C Set	
	(09951-05010) Hanger 150	Tilt steering column Power tilt and power telescopic steering column
	(09952-05010) Slide Arm	Tilt steering column Power tilt and power telescopic steering column
	(09953-05010) Center Bolt 100	Tilt steering column Power tilt and power telescopic steering column
	(09954-05020) Claw No.2	Tilt steering column Power tilt and power telescopic steering column

	09950-60010 Replacer Set	
	(09951-00180) Replacer 18	PS gear
	(09951-00260) Replacer 26	PS gear
	(09951-00280) Replacer 28	PS gear
	(09951-00320) Replacer 32	PS gear
	(09951-00330) Replacer 33	PS vane pump PS gear
	(09951-00350) Replacer 35	PS gear
	(09951-00360) Replacer 36	PS gear
	(09951-00550) Replacer 55	PS gear
	(09952-06010) Adapter	PS gear
	09950-70010 Handle Set	
	(09951-07100) Handle 100	PS vane pump PS gear
	(09951-07150) Handle 150	PS gear

PREPARATION - STEERING

	(09951-07200) Handle 200	PS gear
	(09951-07360) Handle 360	PS gear
	09960-10010 Variable Pin Wrench Set	
	(09962-01000) Variable Pin Wrench Arm Assy	PS vane pump
	(09963-01000) Pin 10	PS vane pump