

INSTALLATION

Installation is in the reverse order of removal (See page [SA-81](#)).

AFTER INSTALLATION, FILL BRAKE RESERVOIR WITH BRAKE FLUID, BLEED BRAKE SYSTEM (See page [BR-4](#)), CHECK FOR LEAKS AND ABS SPEED SENSOR SIGNAL (See page [DI-219](#))