

TORQUE SPECIFICATION

Part tightened	N·m	kgf·cm	ft·lbf
Crossmember x Frame	50	510	37
Crossmember x Engine rear mounting	74	750	54
Transfer x Transmission	69	700	51
Filler and drain plug	37	380	27
Oil pump plate and separator x Rear extension housing	4.9	50	43 in.·lbf
Oil pump cover x Rear extension housing	4.9	50	43 in.·lbf
Lever lock pin	12	120	9
Oil strainer x Rear case	4.9	50	43 in.·lbf
Oil receiver x Front case	12	120	9
Case cover x Rear case	37	380	27
Rear extension housing x Rear case	37	380	27
Front extension housing x Front case	37	380	27
Center diff. lock indicator switch	37	380	27
L position switch	37	380	27
Neutral position switch	37	380	27
Screw plug x Front case	19	190	14
Screw plug x Rear extension housing	29	300	22
Motor actuator x Front case	18	185	13
Differential front case x Differential rear case (temporarily tighten)	98 88	1,000 900	72 65
Front case x Rear case	37	380	27
Crossmember x Transfer case protector	24	250	18
Speed sensor driven gear	11	115	8
Transfer shift lever rod assembly x Shift outer lever	14	140	10
Transfer control shift lever retainer x Transmission	29	300	22