




STARTER COMPONENTS

ST08B-01




B04657





Magnetic Switch Assembly



◆ Non-reusable part

B04547