




THEFT DETERRANT




T5 (A), T6 (B)
THEFT DETERRENT ECU




THEFT DETERRANT



T5 (A), T6 (B)
THEFT DETERRENT ECU



THEFT DETERRANT



SERVICE HINTS

D18, D19 DOOR KEY ;LOCK AND UNLOCK SW LH, RH

1-3 : Closed with door lock cylinder unlocked with key

2-3 : Closed with door lock cylinder locked with key

B3 BACK DOOR KEY LOCK AND UNLOCK SW

1-3 : Closed with door lock cylinder unlocked with key

1-2 : Closed with door lock cylinder locked with key

E3 ENGINE HOOD COURTESY SW

2-1 : Closed with ignition key in cylinder

U1 UNLOCK WARNING SW

1-3 : Closed with engine hood open

T5 (A), T6 (B) THEFT DETERRENT ECU

(A) 6-GROUND : Continuity with ignition key in cylinder

(A) 15-GROUND : Continuity with front RH door unlocked

(A) 14-GROUND : Continuity with front LH door unlocked

(A) 5-GROUND : Continuity with front RH door open

(A) 4-GROUND : Continuity with front LH door open

(A) 8-GROUND : Continuity with door key lock SW at **LOCK** position

(B) 7-GROUND : Always continuity

(A) 3-GROUND : Continuity with engine hood open

(A) 9, (B) 10-GROUND : Continuity with door key lock SW at **UNLOCK** position

(A) 11, (B) 9-GROUND : Always approx. **12** volts

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B2	40	D24	40	J19	39
B3	40	E3	36	J21	39
B4	40	F6	36	J27	39
C9	38	I19	A 38	J32	40
D14	40	I20	B 38	J33	40
D15	40	I21	C 38	J34	40
D16	40	J1	39	T1	37
D17	40	J9	39	T5	A 39
D18	40	J10	39	T6	B 39
D19	40	J11	39	U1	39
D21	40	J14	39	W3	39
D22	40	J15	39		
D23	40	J16	39		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	21	Engine Room No.2 Wire and Engine Room J/B (Engine Compartment Left)
1C		
1E		
1N	21	Engine Room No.3 Wire and Engine Room J/B (Engine Compartment Left)
2B	24	Dash Wire and Cowl Side J/B LH (Left Kick Panel)
2F	24	Engine Room No.2 Wire and Engine Room J/B LH (Left Kick Panel)
2L	24	Front Door LH Wire and Cowl Side J/B LH (Left Kick Panel)
2M		
2N	24	Floor Wire and Cowl Side J/B LH (Left Kick Panel)
2O		
2P	26	Instrument Panel Integration Wire and Cowl Side J/B LH (Left Kick Panel)
3E	30	Floor No.2 Wire and Cowl Side J/B RH (Right Kick Panel)
3G	30	Front Door RH Wire and Cowl Side J/B RH (Right Kick Panel)
3I	30	Instrument Panel Integration Wire and Cowl Side J/B RH (Right Kick Panel)

THEFT DETERRANT

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA2	44	Engine Room Main Wire and Engine Room No.2 Wire (Engine Compartment Right)
ID1	46	Dash Wire and Floor Wire (Left Kick Panel)
IG1	48	Engine Room No.2 Wire and Dash Wire (Behind the Combination Meter)
IG2		
IL1	48	Instrument Panel Integration Wire and Computer Wire (Instrument Panel Center)
IL2		
IU1	50	Instrument Panel Integration Wire and Dash Wire (Behind the Glove Box)
IU2		
IU4		
IU5		
IW2	52	Engine Room No.2 Wire and Dash Wire (Behind the Glove Box)
BA1	54	Rear Door LH Wire and Floor Wire (Left Side of Center Pillar)
BC1	54	Rear Door RH Wire and Floor No.2 Wire (Right Side of Center Pillar)
BD2	54	Floor No.3 Wire and Floor Wire (Left Rear Side Quarter Panel)
BE1	54	Luggage Room Wire and Floor Wire (Left Rear Side Quarter Panel)
BG1	56	Pillar No.1 Wire and Luggage Room Wire (Left Rear Side Roof Panel)
BH1	56	Pillar No.1 Wire and Back Door Upper Wire (Left Side of Back Door)
BH2		
BK1	56	Back Door Lower Wire and Floor No.3 Wire (Right Side of Rear Floor Crossmember)
BL1	56	Floor No.2 Wire and Floor No.3 Wire (Right Side of Rear Floor Crossmember)

: GROUND POINTS

Code	See Page	Ground Points Location
EA	44	Front Right Side of Fender Apron
IF	46	Set Bolt of Cowl Side J/B LH
II	46	Set Bolt of Cowl Side J/B RH
BJ	54	Under the Driver's Seat
BK	54	Front Side Under the Front Passenger's Seat
BM	54	Left Rear Side Quarter Panel


: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B1	56	Front Door LH Wire	B15	56	Back Door Upper Wire
B14	56	Floor No.2 Wire			


B2




B3



B4
BLACK



C9



D14



D15



D16



D17




D18
GRAY




D19
GRAY




D21
BLACK



D22
BLACK





F6
(See Page 34)

