


















TRANSFER (Part-Time 4WD Type)





SST (Special Service Tools)

PP211-01

	09309-60010	Extension Pipe	Front extension housing
	09316-20011	Transfer Bearing Replacer	Front extension housing Output shaft, Transfer assembly
	09316-60011	Transmission & Transfer Bearing Replacer	
	(09316-00011)	Replacer Pipe	Front extension housing Output shaft, Transfer assembly
	(09316-00031)	Replacer "B"	Front extension housing Transfer assembly
	(09316-00061)	Replacer "E"	Front extension housing
	(09316-00071)	Replacer "F"	Front extension housing
	09330-00021	Companion Flange Holding Tool	Transfer assembly
	09517-12010	Rear Axle Shaft Oil Seal Replacer	Transfer assembly
	09631-20081	Seal Ring Tool	Transfer assembly
	09649-17010	Steering Knuckle Tool	Front extension housing
	09950-00020	Bearing Remover	Output shaft

	09950-40011 Puller B Set	
	(09951-04020) Hanger 200	Front extension housing Transfer assembly
	(09952-04010) Slide Arm	Front extension housing Transfer assembly
	(09953-04030) Center Bolt 200	Front extension housing Transfer assembly
	(09954-04010) Arm 25	Front extension housing Transfer assembly
	(09955-04021) Claw No.2	Front extension housing Transfer assembly
	(09955-04051) Claw No.5	Front extension housing
	(09955-04061) Claw No.6	Transfer assembly
	(09957-04010) Attachment	Transfer assembly Front extension housing
	(09958-04011) Holder	Transfer assembly
	09950-60010 Replacer Set	
	(09951-00270) Replacer 27	Transfer assembly
	(09951-00290) Replacer 29	Transfer assembly

PREPARATION – TRANSFER (Part-Time 4WD Type)

	(09951-00320) Replacer 32	Transfer assembly
	(09951-00400) Replacer 40	Transfer assembly
	09950-60020 Replacer Set No.2	
	(09951-00790) Replacer 79	Transfer assembly
	(09951-00890) Replacer 89	Transfer assembly
	09950-70010 Handle Set	
	(09951-07150) Handle 150	Transfer assembly