




INSPECTION

INSPECT STEERING RACK

- (a) Using a dial indicator, check the rack for runout and for teeth wear and damage.

Maximum runout: 0.03 mm (0.012 in.)

- (b) Check the back surface for wear and damage.