


HOW TO READ THIS SECTION

* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the wiring diagram section.



[A] : System Title


[B] : Indicates the wiring color.

Wire colors are indicated by an alphabetical code.

B = Black W = White BR = Brown
L = Blue V = Violet SB = Sky Blue
R = Red O = Orange LG = Light Green
P = Pink Y = Yellow GR = Gray
G = Green

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L – Y




[C] : The position of the parts is the same as shown in the wiring diagram and wire routing.

[D] : Indicates the pin number of the connector.


The numbering system is different for female and male connectors.

Example : Numbered in order from upper left to lower right

Numbered in order from upper right to lower left



Female



Male


The numbering system for the overall wiring diagram is the same as above

[E] : Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example : ① Indicates Relay Block No.1


[F] : Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.

Example:



[G] : Indicates related system.

[H] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (↗). Outside numerals are pin numbers.



[I] : () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.

[J] : Indicates a shielded cable.



[K] : Indicates and located on ground point.

[L] : The same code occurring on the next page indicates that the wire harness is continuous.

SYSTEM INDEX

SYSTEMS	LOCATION	SYSTEMS	LOCATION
ABS	14-3	Power Rear Quarter Window	23-3
Auto Antenna	11-3	Power Seat	19-3
Automatic Light Control	9-4	Power Source	1~30-1
Back-Up Light	8-2	Power Tilt and Power Telescopic	20-3
Center Differential Lock	15-3	Power Window	18-3
Charging	1-4	Radio and Player	27-3
Cigarette Lighter	25-2	Rear Air Conditioning	30-3
Clock	22-4	Rear Differential Lock	16-3
Combination Meter	28-3	Rear Heater (w/o Rear Air Conditioning)	26-3
Condenser Fan	29-2	Rear Window Defogger and Mirror Heater	23-2
Cruise Control	13-2	Rear Wiper and Washer	9-2
Door Lock Control	9-12	Remote Control Mirror	21-3
Electronically Controlled Transmission and A/T Indicator	13-3	Seat Heater	25-3
Engine Control and Engine Immobiliser System	2-3	Shift Lock	11-2
Front Air Conditioning	29-4	SRS	12-3
Front Fog Light	4-2	Starting	1-2
Front Wiper and Washer	10-2	Stop Light	8-3
Headlight	4-3	Taillight	6-3
Horn	10-4	Theft Deterrent	17-3
Ignition	3-3	Turn Signal and Hazard Warning Light	5-3
Illumination	7-3	Wireless Door Lock Control	9-19
Interior Light	9-6		
Key Reminder and Seat Belt Warning	24-2		
Light Auto Turn Off	21-2		
Moon Roof	24-4		
Power Outlet	22-2		