

INSTALLATION

Installation is in the reverse order of removal ([See page BR-28](#)).

HINT:

- After installation, fill the brake reservoir with brake fluid and bleed brake system ([See page BR-1](#)).
- Check for leaks.