

# ABS & VEHICLE STABILITY CONTROL (VSC) & BRAKE ASSIST (BA) SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

DI6WY-01

Troubleshooting in accordance with the procedure on the following pages.

