

INSTALLATION

Installation is in the reverse order of removal ([See page BR-27](#)).

HINT:

- After installation, fill the brake reservoir with brake fluid and bleed brake system (See Pub. No. RM731E on page BR-1).
- Check for leaks.