

INSTALLATION

Installation is in the reverse order of removal (See page [BR-60](#)).

HINT:

- After installation, fill the brake reservoir with brake fluid and bleed brake system (See page [BR-4](#)).
- Check for leaks.