

ENGINE IMMOBILISER SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

DI1AJ-06

Troubleshoot in accordance with the procedure on the following pages.

