




CYLINDER HEAD COMPONENTS


EMOKZ-04




A09750



Heated Oxygen Sensor
(Bank 2 Sensor 1)






Heated Oxygen Sensor
(Bank 1 Sensor 1)




N·m (kgf·cm, ft·lbf) : Specified torque
◆ Non-reusable part


A05716





A04461





N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A05527