






















ENGINE MECHANICAL




SST (Special Service Tools)

PP1BK-02

	09201-10000	Valve Guide Bushing Remover & Replacer Set	
	09201-01055	Valve Guide Bushing Remover & Replacer 5.5	
	09201-41020	Valve Stem Oil Seal Replacer	
	09202-70020	Valve Spring Compressor	
	(09202-00010)	Attachment	
	09213-54015	Crankshaft Pulley Holding Tool	
	09222-30010	Connecting Rod Bushing Remover & Replacer	
	09223-46011	Crankshaft Front Oil Seal Replacer	Crankshaft pulley Crankshaft timing pulley
	09223-56010	Crankshaft Rear Oil Seal Replacer	
	09316-60011	Transmission & Transfer Bearing Replacer	
	(09316-00011)	Replacer Pipe	Crankshaft front oil seal
	09330-00021	Companion Flange Holding Tool	Crankshaft pulley

PREPARATION - ENGINE MECHANICAL

	09843-18020	Diagnosis Check Wire	
	09950-50012	Puller C Set	
	(09951-05010)	Hanger 150	Crankshaft pulley Crankshaft timing pulley
	(09952-05010)	Slide Arm	Crankshaft pulley Crankshaft timing pulley
	(09953-05010)	Center Bolt 100	Crankshaft pulley Crankshaft timing pulley
	(09953-05020)	Center Bolt 150	Crankshaft pulley Crankshaft timing pulley
	(09954-05010)	Claw No.1	Crankshaft timing pulley
	(09954-05020)	Claw No.2	Crankshaft pulley
	09950-60010	Replacer Set	
	(09951-00240)	Replacer 24	
	(09951-00460)	Replacer 46	
	(09952-06010)	Adapter	
	09950-70010	Handle Set	

	(09951-07100) Handle 100	Spark plug tube Valve guide bushing
	09960-10010 Variable Pin Wrench Set	
	(09962-01000) Variable Pin Wrench Arm Assy	Camshaft sub-gear
	(09963-01000) Pin 10	Camshaft sub-gear
	(09963-00500) Pin 5	Camshaft sub-gear