

30. CD magazine inserted, but no power.**INSPECTION PROCEDURE****1 Is radio operating normally?****YES****Go to step 5.****NO****2 Check CIGER fuse is OK?****NG****Replace fuse.****OK****3 Is power supplied to ACC terminal of stereo component amplifier?****NO****ACC wire harness faulty.****YES****4 Is power supplied to ACC terminal of radio receiver assembly?****NO****Stereo component amplifier faulty.****YES****Radio receiver assembly faulty.**

