



PARTS LOCATION



Engine Room Junction Block
● EFI Fuse
● EFI and ECD Relay



Driver Side Junction Block
● IGN Fuse

DLC3

ECM

P

109907