

29. DVD MAGAZINE CANNOT BE INSERTED

INSPECTION PROCEDURE

1 Is DVD magazine already inserted?

YES

Eject DVD magazine.

NO

2 Is auto search button of radio operating normally?

YES

Go to step 6.

NO

3 Check if RADIO fuse is OK?

NG

Replace RADIO No. 1 fuse.

OK

4 Is power supplied to +B terminal of stereo component amplifier?

NO

+B wire harness faulty.

YES

5	Check if GND (wire harness side) of radio receiver assembly.
----------	---

NG**+B wire harness faulty.****OK****Radio assembly faulty.**

6	Is power supplied to +B terminal of DVD auto changer?
----------	--

No**Radio receiver assembly faulty.****YES**

7	Check if GND (wire harness side) of DVD auto changer grounded normally?
----------	--

NG**Radio receiver assembly faulty.****OK****DVD auto changer faulty.**