




CYLINDER HEAD COMPONENTS


EMOKZ-04




A09750



Heated Oxygen Sensor
(Bank 2 Sensor 1)





Heated Oxygen Sensor
(Bank 1 Sensor 1)





N·m (kgf·cm, ft·lbf) : Specified torque
◆ Non-reusable part

A05716









N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A05527