



STARTER COMPONENTS

ST08B-02




P


B06490



B04660



Magnetic Switch Assembly



◆ Non-reusable part

B04547