

INSTALLATION

Installation is in the reverse order of removal (See page [SA-84](#)).

HINT:

After installation, fill the brake reservoir with brake fluid, bleed the brake system (See page [BR-4](#)), check for leaks and check the ABS speed sensor signal (See page [DI-229](#) or [DI-318](#)).