

TORQUE SPECIFICATION

Part tightened		N·m	kgf·cm	ft·lbf
Transmission housing x Transmission case	14 mm	34	345	25
	17 mm	57	581	42
Automatic transaxle breather tube x Transmission case		5.4	55	48 in.·lbf
Park/Neutral position switch assy	Bolt	13	130	9
	Nut	6.9	70	61 in.·lbf
Transmission wire x Transmission case		5.4	55	48 in.·lbf
Oil cooler tube union x Transmission case		29	296	21
Transmission control shaft lever LH		16	163	12
Transmission revolution sensor x Transmission case		5.4	55	48 in.·lbf
Extension housing assy x Transmission case (A750E)		34	345	25
Transmission case adapter adapter x Transmission case (A750F)		34	345	25
Oil pan x Transmission case		4.4	45	39 in.·lbf
Valve body oil strainer assy x Transmission valve body assy		10	100	7
Transmission valve body assy x Transmission case		11	110	8
Parking lock pawl bracket x Transmission case		7.4	75	65 in.·lbf
Drain plug		28	285	21
Oil pump x Transmission case		21	214	15
Oil pump body x Stator shaft assy		12	122	9
Lock plate x Transmission valve body assy		6.4	65	57 in.·lbf
Shift solenoid valve SR x Transmission valve body assy		6.4	65	57 in.·lbf
Shift solenoid valve S1 x Transmission valve body assy		6.4	65	57 in.·lbf
Shift solenoid valve S2 x Transmission valve body assy		10	100	7
ATF Temperature sensor x Transmission valve body assy	36 mm	11	112	8
	12 mm	10	100	7