

D RELAY LOCATIONS

○ : Cowl Side J/B LH	LHD : Left Kick Panel (See Page 9)
	RHD : Left Kick Panel (See Page 10)
(Inner Circuit : See Page 24)	

