


[Instrument Panel] (LHD1)



(LHD2)

- * 5:w/ Front Diff. Lock
- * 6:w/o Front Diff. Lock
- * 7:w/ Center Diff. Lock
- * 8:w/o Center Diff. Lock
- * 9:A/T Except *2
- *10:M/T Except 1HZ
- *11:1HZ

