


E ELECTRICAL WIRING ROUTING

Position of Parts in Body

[LHD : Swing Type]



P 7 Parking Brake SW
 P 8 Power Outlet (Luggage Compartment)
 P12 Power Window Control SW Front RH
 P13 Power Window Control SW Rear LH
 P14 Power Window Control SW Rear RH
 P15 Power Window Master SW
 P17 Power Window Motor Front LH
 P18 Power Window Motor Front RH
 P19 Power Window Motor Rear LH
 P20 Power Window Motor Rear RH
 P21 Pretensioner LH
 P22 Pretensioner RH

R13 Rear A/C Control SW
 R14 Rear Air Mix Control Servo Motor
 R15 Rear Combination Light LH
 R17 Rear Combination Light RH
 R19 Rear Cooler Blower Motor
 R20 Rear Cooler Magnetic Valve
 R21 Rear Cooler Power Transistor
 R22 Rear Cooler Relay
 R23 Rear Diff. Lock Motor
 R24 Rear Door Speaker LH

R25 Rear Door Speaker RH
 R26 Rear Evaporator Temp. Sensor
 R27 Rear Heater Blower Motor
 R28 Rear Heater Blower Resistor
 R30 Rear Heater Power Transistor
 R31 Rear Heater Relay
 R32 Rear Inlet Air Temp. Sensor
 R33 Rear Interior Light
 R34 Rear Personal Light
 R37 Rear Window Defogger LH
 R38 Rear Window Defogger LH
 R39 Rear Window Defogger RH
 R40 Rear Window Defogger RH
 R42 Rear Wiper Motor LH
 R43 Rear Wiper Motor RH
 R44 Rear Wiper Relay
 R47 Remote Control Mirror ECU
 R48 Remote Control Mirror LH
 R49 Remote Control Mirror RH
 R50 Room Temp. Sensor (Rear)
 R58 Rain Sensor
 R59 Rear Cooler Blower Resistor
 R60 Rear Fog Light