


Position of Parts in Instrument Panel

[RHD]



C 6 CD Automatic Changer
C 8 Center Diff. Lock Control Relay
C 13 Cigarette Lighter
C 14 Cigarette Lighter Illumination
C 15 Combination Meter
C 16 Combination Meter
C 17 Combination Meter
C 18 Combination Meter
C 19 Combination SW
C 20 Combination SW
C 22 Combination SW
C 23 Cooler Box
C 24 Cruise Control Clutch SW
C 32 Center Cluster Integration Panel
C 33 Combination SW

D 5 Damping Mode Select SW and Height Control SW
D 8 DLC3
D 9 Door Lock Control SW
D 33 Deceleration Sensor
D 34 Diode (Front Fog No.2)
D 35 Diode (Viscous Heater1)
D 36 Diode (Viscous Heater2)
D 37 Double Lock Control Relay

E 4 ECT ECU
E 5 ECT ECU
E 6 ECT Pattern Select SW
E 7 Engine and ECT ECU
Engine ECU
E 8 Engine and ECT ECU
Engine ECU
E 9 Engine and ECT ECU
Engine ECU
E 10 Engine and ECT ECU
Engine ECU

E 11 Engine and ECT ECU
Engine ECU
E 12 Engine and ECT ECU
Engine ECU
E 13 Engine and ECT ECU
Engine ECU
E 14 Engine and ECT ECU
Engine ECU
E 16 Engine and ECT ECU
Engine ECU
E 17 Engine and ECT ECU
Engine ECU
E 18 Engine and ECT ECU
Engine ECU
E 19 Engine and ECT ECU
Engine ECU
E 21 Emission Control ECU
E 22 Emission Control ECU

F 19 Front Blower Motor
F 20 Front Blower Resistor
F 21 Front/Rear Diff. Lock Control SW
F 22 Fuel Tank Changeover SW
F 27 Front/Rear Diff. Lock Control ECU

G 3 Glove Box Light
G 4 Gateway ECU

H 19 Headlight Beam Level Control SW
H 23 Headlight Cleaner SW

I 24 Idle-Up SW
I 26 Ignition SW