

DTC	C1516 / 16	VGRS Actuator Neutral Position Incomplete
------------	-------------------	--

CIRCUIT DESCRIPTION

This code is set when the VGRS system calibration procedure does not complete normally.

DTC No.	DTC Detecting Condition	Trouble Area
C1516/16	The VGRS actuator angle adjustment did not complete normally.	• VGRS actuator • VGRS ECU

INSPECTION PROCEDURE

1	Clear DTC (See page DI-348).
----------	---

NEXT

2	Perform VGRS system calibration (See page DI-357).
----------	---

NEXT

3	Is DTC C1516/16 output?
----------	--------------------------------

NO

VGRS system calibration is completed.

YES

4	Is DTC C1532/32 output?
----------	--------------------------------

YES

Replace VGRS ECU.

NO

Proceed to step 5.

