

CRUISE MAIN Indicator Light Circuit

CIRCUIT DESCRIPTION

When the cruise control main switch is turned ON, CRUISE MAIN indicator light lights up.

INSPECTION PROCEDURE

1	Perform Active Test of hand-held tester.
---	--

PREPARATION:

Connect the hand-held tester to the DLC3.

CHECK:

Check the cruise indicator of the combination meter using Active Test.

OK:

Description	Tester display	Check condition
CRUISE Indicator light	CRUISE INDIC	ON/OFF

OK

Proceed to next circuit inspection shown on problem symptom table ([See page DI-865](#)).

NG

Check and replace combination meter.
([See page IN-38](#)).