



PARTS LOCATION



Engine Room R/B
• EFI Fuse

Transponder Key ECU



Transponder Key
Amplifier w/coil

ECM

Cowl Side J/B LH
• IGN Fuse

DLC3

H

I26015