


# Stop Light Switch Circuit

## CIRCUIT DESCRIPTION

This circuit sends a stop light switch ON or OFF signal to ECU.


## WIRING DIAGRAM



C

I26332

## RHD Models:



(): 1HD-FTE

C

I26332

**INSPECTION PROCEDURE****1** Check stop light switch .**NG**

Replace stop light switch.

**OK****2** Check wire harness between stop light switch and wiper control ECU ([See page IN-38](#)).**NG**

Repair or replace wire harness.

**OK**Proceed next circuit inspection shown on problem symptom table. ([See page DI-930](#))