


TERMINALS OF ECU


● Body ECU



H

DIA 124951


● Rain Sensor



H


I24944

● Double Lock ECU



I26065


● Wiper Control ECU



H


I24937

● Power Seat Control ECU




I24936

● Theft Deterrent ECU



I24938



● Mirror Control ECU



T



I20398

- Power Window Master Switch
- Power Window Switch Front RH (P12) (LHD)
- Power Window Switch Rear LH (P13)
- Power Window Switch Rear RH (P14)



I26008

● Tilt and Telescopic ECU



F05341