

PROBLEM SYMPTOMS TABLE

Flow chart No. (See page)	Component	Symptom
1. (DI-1178)	Multi display	Black screen (Nothing displayed)
2. (DI-1179)		No sound with Power switch pressed. ("AUTO OFF" on audio screen)
3. (DI-1182)		No navigation screen displayed when "MAP", "MENU" or "DEST" switch pressed. (Screen cannot be switched.)
4. (DI-1184)		No corresponding screen displayed when "AUDIO" or "Information" switch pressed.
5. (DI-1185)		No navigation displayed, "Audio OFF" on audio screen and no audio sound.
6. (DI-1187)		Screen cannot be dimmed in night time.
7. (DI-1188)		Navigation screen not stabilized. (Synchronous error)
8. (DI-1189)		Color on navigation screen is unusual (RGB signal error)
9. (DI-1191)		Black screen appears when "MAP", "Menu" or "DEST" switch pressed.
10. (DI-1192)		Sound of radio, cassette tape or CD only cannot be heard from speaker.
11. (DI-1193)		No sound (radio, cassette tape, CD) can be heard from driver side door speaker only.
12. (DI-1195)		Map DISC cannot be inserted.
13. (DI-1197)		MAP screen display does not appear. (Disc Caution screen does not change.)
14. (DI-1198)		MAP is displayed in white or blue screen. (Switch and vehicle position mark is displayed.)
15. (DI-1199)		Touch switch does not function. (Navigation screen only)
16. (DI-1200)		Touch switch does not function. (A/C control screen only)
17. (DI-1201)		Panel switch does not function. (Navigation screen only)
18. (DI-1202)		Panel switch does not function. (A/C control screen only)
19. (DI-1203)		The screen cannot be change to night mode color.
20. (DI-1205)		Vehicle position is deviated from correct point badly.
21. (DI-1208)		GPS mark does not appear.

22. (DI-1210)		No voice navigation.
23. (DI-1211)		Vehicle position rotates without control. (Map rotates without control)
24. (DI-1213)		Driving direction is opposite to moving direction of vehicle position mark.
25. (DI-1214)		Navigation system cannot be operated with voice recognition.