

8. Color on navigation screen is unusual (RGB signal error).**INSPECTION PROCEDURE**

1 Display check mode (Color bar check).

NG

Replace the multi display.

2 Navigation check mode (Color bar check).

NG

Go to step 4.

OK

3 Check the screen setting (Day or Night mode).

OK

Normal.

NG

4 Check the navigation ECU.**CHECK:**

Check terminals +B.

OK:

+B: 10 – 14 V

CHECK:

Check terminal ACC when turn ignition switch ACC or ON position.

OK:

ACC: 10 – 14 V

CHECK:

Check terminal R, G, B, VR or VG.

OK:

R, G, B, VR or VG: See "Navigation ECU" of "TERMINAL OF ECU"

NG

Repair or replace the wire harness when all terminals are faulty. Replace the navigation ECU when R,G,B terminal is faulty.

OK**Replace the multi display.**