

DTC	B2784	TRANSPONDER KEY COIL MALFUNCTION
------------	--------------	---

CIRCUIT DESCRIPTION

This DTC is output when short or open of the key coil built in the transponder key amplifier is detected.

DTC No.	DTC Detecting Condition	Trouble Area
B2784	Transponder key coil malfunction	Transponder key amplifier with coil

INSPECTION PROCEDURE

Replace key.