



# STARTER COMPONENTS

ST08B-03




P


B16434



B16458



### Magnetic Switch Assembly



◆ Non-reusable part

B04547