

D RELAY LOCATIONS

○ : Cowl Side J/B LH	LHD : Left Kick Panel (See Page 9) RHD : Left Kick Panel (See Page 10)
-----------------------------	--

(Inner Circuit : See Page 24)

