


E ELECTRICAL WIRING ROUTING

Position of Parts in Body

[RHD : Swing Type]



P 7 Parking Brake SW
P 8 Power Outlet (Luggage Compartment)
P 11 Power Window Control SW Front LH
P 13 Power Window Control SW Rear LH
P 14 Power Window Control SW Rear RH
P 15 Power Window Master SW
P 17 Power Window Motor Front LH
P 18 Power Window Motor Front RH
P 19 Power Window Motor Rear LH
P 20 Power Window Motor Rear RH
P 21 Pretensioner LH
P 22 Pretensioner RH

R 13 Rear A/C Control SW
R 14 Rear Air Mix Control Servo Motor
R 15 Rear Combination Light LH
R 17 Rear Combination Light RH
R 19 Rear Cooler Blower Motor
R 20 Rear Cooler Magnetic Valve
R 21 Rear Cooler Power Transistor
R 22 Rear Cooler Relay
R 23 Rear Diff. Lock Motor
R 24 Rear Door Speaker LH

R 25 Rear Door Speaker RH
R 26 Rear Evaporator Temp. Sensor
R 27 Rear Heater Blower Motor
R 28 Rear Heater Blower Resistor
R 30 Rear Heater Power Transistor
R 31 Rear Heater Relay
R 32 Rear Inlet Air Temp. Sensor
R 33 Rear Interior Light
R 34 Rear Personal Light
R 37 Rear Window Defogger LH
R 38 Rear Window Defogger LH
R 39 Rear Window Defogger RH
R 40 Rear Window Defogger RH
R 42 Rear Wiper Motor LH
R 43 Rear Wiper Motor RH
R 44 Rear Wiper Relay
R 47 Remote Control Mirror ECU
R 48 Remote Control Mirror LH
R 49 Remote Control Mirror RH
R 50 Room Temp. Sensor (Rear)
R 58 Rain Sensor
R 59 Rear Cooler Blower Resistor
R 60 Rear Fog Light