


ABS & VEHICLE STABILITY CONTROL (VSC) & BRAKE ASSIST (BA) SYSTEM

DIC8N-01

HOW TO PROCEED WITH TROUBLESHOOTING

Troubleshoot in accordance with the procedure on the following pages.



Fail safe function:

When a failure occurs in the ABS & BA & TRAC & VSC systems, the ABS and VSC warning lights are lit and ABS & BA & TRAC & VSC operation is prohibited. In addition to this, when the failure which disables EBD operation occurs, the BRAKE warning light is lit as well and EBD operation is prohibited.