

13. MAP screen display does not appear. (Disc Caution screen does not change)

INSPECTION PROCEDURE

1 Take appropriate measures according to the caution screen.

OK

Normal

NG

2 Check map DISC.

NG

Replace the disc.

OK

Replace the navigation ECU.

CAUTION SCREEN

CAUTION MESSAGE	CAUSE	CORRECTIVE ACTION
The DVD cover is open. Close it and perform operation again.	The cover of the map disk slot is open.	Close the cover,
No DVD. Please insert map DVD.	No map disk is inserted.	Insert a proper map disc.
Unable to read DVD correctly. Check if the DVD is damaged or dirty.	Data cannot be read because the map disc is dirty or scratched.	Wipe off dirt on the both disc surface with soft cloth.
Unable to read data. Check if map DVD is correct.	Something other than map disc is inserted.	Insert a correct map disc.
Unable to read data. Temperature is too high.	Pick-up part of the player is heated to a high temperature.	Stop the vehicle at a shaded cool place and turn the ignition switch OFF. When confirming that the temperature of the navigation ECU has been lowered, turn the ignition switch ON.
Unable to read data. Contact your dealer.	The player cannot read data from the map disc temporarily.	Turn the ignition switch OFF and ON.*1

*1: If the same caution screen appears again after turning the ignition switch ON, replace the navigation ECU.