

19. Navigation screen cannot change to the night mode color.

INSPECTION PROCEDURE

- 1 Check the setting. (Is it set to Day Mode in screen adjustment?)

Yes

Normal

No

- 2 Check if the screen is dimmed at night. (With the light control switch ON, do all screens except the navigation screen appear in Night Mode?)

NG

Go to step 5.

OK

- 3 Does the beep sound by operating switches on the navigation screen?

OK

Replace the navigation ECU.

NG

- 4 Check "AVC-LAN communication circuit". (See page [DI-1263](#))

NG

Replace or repair AVC-LAN circuit.

OK

Replace the navigation ECU.

5	Check the multi display.
----------	---------------------------------

CHECK:

Measure the voltage between terminal DR and GND1 of the multi-display.

OK:

DR: Above 9 V

OK

Replace the multi display.

NG

Replace or repair wire harness.