

26. Any speaker does not work. (DVD sound only)

INSPECTION PROCEDURE

1

Check wire harness and connector between DVD auto changer and radio receiver (See page [IN-36](#)).

NG

Repair or replace wire harness or connector.

OK

Check and replace the DVD auto changer.