

27. DVD MAGAZINE CANNOT BE INSERTED

INSPECTION PROCEDURE

1	Is DVD magazine already inserted?
---	-----------------------------------

YES

Eject DVD magazine.

NO

2	Check the DVD auto changer.
---	-----------------------------

PREPARATION:

Disconnect the DVD auto changer connector.

CHECK:

Check voltage terminals +B.

OK:

+B: 10 – 14 V

CHECK:

Check voltage terminal ACC when turn ignition switch ACC or ON position.

OK:

ACC: 10 – 14 V

CHECK:

Check continuity terminal GND.

OK:

GND: Continuity

NG

Replace or repair wire harness or connector.

OK

Check and replace DVD auto changer.